



ISO 9001
REGISTERED

NEW-FLOW


MANUFACTURE OF PLATIC TUBE FLOW METER

BPF-300 SERIES

AND CONTROL INSTRUMENTS

塑膠管流量計操作說明書

Instruction Manual



Approvals:



Patent No.

Taiwan: M358295/M332836
China: 1187801

NEW-FLOW TECHNOLOGIES, INC.

No.9 Lane 133, Xing-Hua St., Chien Chen Dist., Kaohsiung 806, Taiwan

TEL: 886-7-8135500 FAX: 886-7-8225588 / 8159758

Email: info@new-flow.com www.new-flow.com

INSTALLATION

Instructions Manul 用法說明

BF300 flow meter consist of, fixed orifice, float and indicator.

Float and indicator provide one set of magnetic coupling in each side.

Fluid turn thought float affects another magnet in mechanical indicator to indicating flow rate on dial scale.


BF300 流量計是由固定流孔板、浮球和指針所組成。

浮球和指針在每邊各提供一組耦合的磁鐵機構。


當流體通過浮球時會牽動另一個機械式指針裡的磁鐵，同時指針就會在刻度盤上顯示流量。

Alarm/Analog Output 接點/類比輸出


BF-300/GS-M (Micro Switch)




BF-300/GT (Analog Output)




BF-300/GS-C (Inductive Switch)



Principle 原理




Dimensions 尺寸



INSTALLATION

Installation Method 安裝方法




SPECIAL NOTE


No minimum length requirement for straight pipe.

BF-300 Main Parts List 配件圖示


(A) Inner Photo 內部圖



(B) Scale Photo 表面圖




(C) Necessary Tools 所需工具



Acting Principle 作動原理


1. The micro switch provides SPDT function and offer NO.NC.COM contact for usage.
此開關為micro switch提供，NO.NC.COM接點使用。



2. The revolving cam activates the micro switch to control the flow rate.
由旋轉中的凸輪帶動micro switch 來做流率 (flow rate) 控制。

3. Micro Switch Rating: 5A 110VAC 3A 250VAC
此Micro Switch規格為: 5A 110VAC 3A 250VAC

Revolvable Cam 凸輪



INSTALLATION MAUL OF BF300.GS.M

The Setting Step 設定步驟

1. If the flow range needs to be reseted, please open an upper cover at first and relax the revolable cam(2) with the hexangular key wrench(d). (as diagram B)

若需重新設定流量範圍時，請先打開上蓋，用六角板手(d)放鬆凸輪(2)。(如圖B)

2. Turn the flow pointer(5) to the requested alarm set point with hand at the position (as diagram C). Let the revolable cam touch the micro switch(1) to cause NO, COM short-circuited. When the multimeter displays zero (as diagram D), lock the cam tightly in place.

將流量指針(5)手動旋轉至所需alarm設定點 (此時用手固定暫不放開，如圖C)，並讓凸輪尖端碰觸micro switch(1)，使NO, COM短路，即三用電錶顯示於零時(圖D)，再將凸輪(2)鎖緊固定。

3. Revolve the flow pointer(5) by hand and confirm the alarm setting whether it is correct by multimeter(a) once again.

再次手動旋轉流量指針(5)，並使用三用電錶(a)再次確認alarm設定是否正確。


4. If the alarm set point still incorrect, please repeat 1,2,3 steps until reach the alarm set point that you need.

若alarm設定點依舊不正確，請再重複1,2,3步驟，直到達成您所需之alarm設定點為止。

5. Finally, move the alarm pointer to the alarm of new setting point and lock tightly by “+” driver with hand.


最後將alarm指針移至所設定的新alarm刻度點上用十字螺絲板手鎖緊。

6. If the pointer didn't return zero (as diagram E), when there are not fluid through inside this flow meter. First, we have to keep the flow pointer(5) in zero and adjust the flow pointer in zero with “-” driver to revolve zero adjustable screw.


(as diagram F, )

若指針未歸零時(圖E)，先用手固定流量計指針(5)於零點處，再利用一字螺絲板手(c)調整流量指針螺絲(6)，直到歸零為止(圖F)。


(Diagram B)



(Diagram C)



(Diagram D)



(Diagram E)



(Diagram F)



Notice 注意事項

1. Please watch for the flow direction when you install.
2. After setting completion, please indeed lock the upper cover tightly, and have to a cable gland in entrance fixed cable to make sure water tightly.
3. If the fluid is dirty water or waste water, please installing filter at inlet to avoid fluid jump.


1. 安裝時，請注意流向。
2. 設定完成後，請將上蓋確實鎖緊，並於出線口處做好防水防漏措施。
3. 如果流體為污水或廢水時，請在入口處安裝過濾器，避免造成阻塞。

INSTALLATION MAUL OF BF300.GS.C

Zero Setting And Adjustment 零調設定

Open the upper cover, please take usage of screwdriver to adjust the flow pointer until it stop at zero point. (as photo at right side)

打開上蓋，利用一字螺絲起子調整流量指針螺絲，直到指針停留在零點位置。




Main Parts List 主要零件

The setting step:

Adjust the alarm pointer to request setting point, then let the pointer to match alarm pointer by hand, after that use hexangular wrench to adjust the block slice position by hand to cover inductive sensor making relay out LED lighting on the signal transducer meanwhile to lock block slice on correct position.


設定步驟:

上蓋打開後先把alarm指針調到設定點，利用六角板手調整擋片位置，最後用手轉動流量指針配合訊號轉換器relay out指示燈來判定設定位置是否正確。



The Setting Principle 設定原理

1. Two methods of setting which divides according to percentage of full flow rate. (設定方式分兩種，以全流速之百分比區分。)
2. It has to match signal transducer to use (as diagram A,B). (須搭配訊號轉換器，如圖A,B使用)



(A) 0%~60% of full flow rate:

Beginning no flow rate through this meter, the signal transducer light turns off (as photo B presented). When the flow rate increased reach to the alarm point, the signal transducer light turn on (as photo A presented). But increased flow rate pass over the alarm point meanwhile block slice leave the position of alarm point and signal transducer sensor turns off (as photo B presented).

全流速之0%~60%


先讓擋片遮住sensor(此時訊號轉換器燈亮如圖)，當流速越大，到達設定點的同時，擋片離開sensor位置則sensor off(如右圖所示)。

(B) 60%~100% of full flow rate:

The sensor turns off (no open) at the beginning. (signal transducer light turns off as photo B presented), while the flow rate increased reach to the alarm point, block slice cover the positoin where sensor is and sensor turns on. (as diagram at the right side).

全流速之60%~100%

一開始sensor off(此時訊號轉換器燈滅如圖)，當流速越大，到達設定點的同時，擋片離開sensor位置則sensor on(如右圖所示)。



INSTALLATION MAUL OF BF300.GS.C

3. The specification of signal transducer. (信號轉號器規格如下。)

1 SPDT: 24VDC KFD2-SR2-Ex1.W

115VAC KFD-SR5-Ex1.W


230VAC KFD2-SR6-Ex1.W

2 SPDT: 24VDC KFD2-SR2-Ex2.W

115VAC KFD2-SR5-Ex2.W

230VAC KFD2-SR6-Ex2.W

Inductive Sensor Uni



INSTALLATION MAUL OF BF300. GT

Main Parts List

Output: 4~20mA, 2 wire system

Please keep flow pointer in zero match to 4mA.

BF300-GT doesn't need to calibration in user side at moment.





Photo of Terminals

Connection Diagram



Notice

After setting completion, please indeed lock the upper cover tightly, and have to a cable gland in entrance fixed cable to make sure water tightly.

INSTALLATION MAUL OF BF300.GT

Main Parts List 主要零件


Power Supply: 24 VDC

Output: Linear 4~20mA (2 wires system)

Accuracy: $\pm 2\%$ F.S

Tool: Multimeter, Program Communicator (GTP01), Power Supply (24VDC), “-” Driver
(三用電錶，規劃器GTP01，直流電源供應器24VDC，一字螺絲起子)

Communication Functions: Model GTP01 (additional charge)(規劃器GTP01需另購)



此開關往下，方可設定。

Put this switch down before the program.

Program Communicator
(GTP01)




圖 (A)

Program Steps Method 規劃步驟

Step 1. The junction terminal of program communicator with the circuit board as Fig. A. Then proceed to under steps.

(將規劃器插入基板中，且接線完成後，如圖 A，將面板鎖上並且做流量指針歸零動作。)


排線插入基板中

Connect junction terminal with circuit board.



Step 2. Press and hold down the RESET button for 5 seconds, the LED lamp will light. Then release press and to keep indicating pointer on “0” point of scale. Then press SET button to start proceed another step. LED lamp will become dark.

(按住RESET鈕5秒鐘後，LED會亮。表示可開始規劃。指針在零點位置0%時，按SET。LED滅掉。)



Step 3. To move indicating pointer to 10% of full scale, LED will flashing once on intermittence. Then, press SET button and start another steps.

(指針刻度達全流量之10%時，按SET。)



LED flashing once
LED閃一次

Step 4. To move indicating pointer to 20% of full scale, LED will flashing twice on intermittence. Then, press SET button and start another steps.


(指針刻度達全流量之20%時，按SET。)



LED flashing twice
LED閃兩次

Step 5. To move indicating pointer to 40% of full scale, LED will flashing three times on intermittence. Then, press SET button and start another steps.


(指針刻度達全流量之40%時，按SET。)



LED flashing three times
LED閃三次

Step 6. To move indicating pointer to 60% of full scale, LED will flashing four times on intermittence. Then, press SET button and start another steps.

(指針刻度達全流量之60%時，按SET。)



LED flashing four times
LED閃四次


INSTALLATION MAUL OF BF300.GT

Step 7. To move indicating pointer to 80% of full scale, LED will flashing five times on intermittence. Then, press SET button and start another steps.
(指針刻度達全流量之80%時，按SET。)






LED flashing five times
LED閃五次

Step 8. To move indicating pointer to 100% of full scale, LED will flashing six times on intermittence. Then, press SET button. LED will become dark. At the meantime, the procedure of program sets are finished.
(指針刻度達全流量之100%時，按SET此時LED滅即表示規劃完成。)



LED flashing six times
LED閃六次

Step 9. After completion the above-mentioned steps, please check of the flow rate 0~100% compare with the output signal 4~20mA or not. If output signal can't match to the flow indicator as under flow table of step 10, it should be re-set again according to Program Steps Method. (規劃完成後，請檢查流量0~100%是否配合4~20mA之輸出訊號。如輸出訊號有誤或誤差太大，請重新規劃。)



Step 10. Flow table and output signal (example: flow range 0~2000 LPH) (以上規劃範例流量為 0~2000 LPH)

| mA | % | LPH | LED狀態 |
|------|-----|------|-----------------------|
| 4 | 0 | 0 | Off 滅 |
| 5.6 | 10 | 200 | Flash once 閃一次 |
| 7.2 | 20 | 400 | Flash twice 閃兩次 |
| 10.4 | 40 | 800 | Flash three times 閃三次 |
| 13.6 | 60 | 1200 | Flash four times 閃四次 |
| 16.8 | 80 | 1600 | Flash five times 閃五次 |
| 20 | 100 | 2000 | Flash six times 閃六次 |



OK. LED off

Notice 注意事項

- Above all, please confirm the input power supply and the wiring mode that are correct.
請確保輸入電源與接線方式是否正確。
- If the process of program set is error, please press and hold down the SET button until the LED lamp turns off. Then re-set it again according to Program Steps Method.
規劃過程中如有誤，請連續按SET鈕直到LED燈滅，再重複規劃步驟。
- Movces the indicator by manual and test run directly after the flow meter completion of installed, all of they are workable.
用手移動指針或流量計安裝完成後直接試車規劃都可行。
- The flow meter has completed program before shipping, therefore it doesn't need to program once more.
產品出貨都已規劃完畢無須再次規劃。
- Put Dit-Switch down before the program.
指撥開關需往下按，才可規劃。