


NEW-FLOW

MANUFACTURE OF FLOW CONSTANT VALVE FOR PURGE METER CVA / CVD

Instruction Manual





NEW-FLOW TECHNOLOGIES, INC.

INSTALLATION

Technical Data

The CVA series is used in where the pressure at the inlet is variable and the pressure at the outlet is constant.

The CVD series is used in where the pressure at the inlet is constant and the pressure at the outlet is vaiable.

Flow Rate:

Liquid: Maximum 200 cc/min water, bigger than it on request Gas: Maximum 30 NL/Min air, bigger than it on request **Process Connection:** 1/4"NPT female, others on request

Temperature Limit: 120°C max.


Pressure Limit: 10 kg/cm², bigger than it on request


Controllable Differential Pressure: Air minimum 0.02 kg/cm²

Maximum 4 kg/cm², liquid minimum 0.2 kg/cm² Maximum 4 kg/cm², special range on request

Accuracy: ±5% F.S.

Material: Body and metal parts-316 stainless steel Membrane-Teflon, option on request





				unit=mm Tolerance: ±10mm
Material	Connection	Flow Constand Valve Model	Flow Meter Model	Range

				Tolerance: ±10mm
Material	Connection	Flow Constand Valve Model	Flow Meter Model	Range

		Tion conocana ranc		 ago
Parts	List			
Item	Part name	Material	Remarks	

Item	Part name	Material	Remarks
1.	CVA Constant Valve	SS316	
2.	FBC Flowmeter	Body Acrylic plastic	
3.	Nipple	SS316	½" x ¼"NPT(M)
4.	Half Union	SS316	ø6 x ¼"NPT(M)
5.	90° Half Union	SS316	ø6 x ¼"NPT(M)
6.	Tube ø6 mm	SS316	
7.	Half Union	SS316	ø6 x ¼"NPT(M)
8.	Tee	SS316	1/4"NPT x 1/4"NPT(F)
9. Nipple 10. Mounting port		SS316	1/4" x 1/4"NPT(M)
		SS316	


Flow Constand Valve Model

CVA

Parts List

Parts List					
	Item Part name		Material	Remarks	
	1.	CVD Constant Valve	SS316		
	2.	FBC Flowmeter	Body Acrylic plastic		
	3.	Nipple	SS316	½" x ¼"NPT(M)	
	4.	Half Union	SS316	ø6 x ¼"NPT(M)	
	5.	90° Half Union	SS316	ø6 x ¼"NPT(M)	
	6.	Tube ø6 mm	SS316		
	7.	Half Union	SS316	ø6 x ¼"NPT(M)	
	8.	Tee	SS316	1/4"NPT x 1/4"NPT(F)	
	9.	Nipple	SS316	1/4" x 1/4"NPT(M)	
	10.	Mounting port	SS316		

Installed Drawing



unit=mr Tolerance: ±10mr


Range

Flow Meter Model

INSTALLATION

Installed Method

Open Tanks Type Installed Method



page 2


Air

Air


INSTALLATION

Purge Set W/Panel


Glass Tube Flow Meter—One Set




Glass Tube Flow Meter—Two Set



Metal Tube Flow Meter— One Set



Metal Tube Flow Meter— Two Set



unit=mm