

NEW-FLOW

MANUFACTURE OF TUNING FORK VIBRATING LEVEL SWITCH VLS5500 SERIES AND CONTROL INSTRUMENTS

Instruction Manual



VLS5500

NEW-FLOW TECHNOLOGIES, INC.


No.9 Lane 133, Xing-Hua St., Chien Chen Dist., Kaohsiung 806, Taiwan TEL: 886-7-8135500 FAX: 886-7-8225588 / 8159758 Email: info@new-flow.com www.new-flow.com

INSTALLATION

Instructions Manul

VLS5500 Series are assembled with a tuning fork and energized sensor. It vibrates frequently with mechanival resonance to detect level of powders or granular bulk solids.

Panel Board Illustrate



- 2 Power Supply
- 3 Sensitivity Adjustment
- (4) Output: SPDT (NC,COM,NO)

1. Switch On

Red light of C101 will be lit when power supply is on. No level showed when green light of C101 is lit. At the meantime, light from red lit change to green lit. When level of material fulling up to level detected point , light from green lit switching to red lit. At the meantime,

(4) output switch SPDT (NC.COM.NO) from NC function change to NO function.


2. Sensitivity Adjustment

Increase the sensitivity for rotating clockwise, rotating counter clockwise to decrease the sensitivity.


3. Test Steps

- a. Adjust the sensitivity by turning (3) clockwise. When red light of C101 is lit, its an indication of oversensitive.
- b. Insert probe into the test liquid, if green light of C101 is lit, it means the test is complete.
- c. If C101 is not light, please repeat the step a. and b. until completion.

Housing Dimensions




Application and Installation



INSTALLATION

Process Connections



Installtion Method

